CENTER LINE

CUT TO THIS LINE

Cut the template out along this line before placing on flat surface of the worktop.

Cut out along this line

FIXING INSTRUCTIONS

1. Fix template to unit and cut out.
2. Apply generous amount of silicon sealant (not supplied) to underside rim and front underside of the basin.
3. Fit the basin into the unit.
4. Remove any excess sealant from top rim of basin.

Given the nature of sanitaryware, each basin varies slightly as to shape and dimensions. For the best fit additional chamfering of the worktop should be done to attain the perfect fit.
All cut surfaces should be sealed to protect against moisture penetration and subsequent damage.

FOLD ALONG DOTTED LINE

Horizontal surface of the worktop

Locate template to the front surface of the fitted worktop as indicated by the arrow.

Thickness of the worktop (varies according to worktop used)

Vertical face of the front fascia

Cut out along this line

B12 1TH - SEMI RECESSED BASIN 58cm 1TH
B12 2TH - SEMI RECESSED BASIN 58cm 2TH

CENTER LINE

Burlington®
Yesterday's designs TODAY'S TECHNOLOGY

D